Alu-Cab™

ULTIMATE OVERLAND PRODUCTS

FITMENT INSTRUCTIONS

INEOS GRENADIER - SAFARI WINDOW SPACER BRACKET

DISCLAIMER

Preliminary information

All rights reserved. No part of this document may be reproduced, translated, stored in a retrieval system. Or transmitted, in any form or by any means, electronic., mechanical, photocopying, recording or otherwise, without prior written permission of the owner.

Review all instruction information carefully before installation.

Any damages, direct or indirect to the installer and/or property due to incorrect installation of any parts are the responsibility of the installer.

Due to the various application and fitment options available, the responsibility lies with the user to ensure all mounting points are secure and tight before every trip. If unsure, consult with your Distributor regarding the operations of our products.

Users are advised to be mindful of the load they are carrying and drive in accordance with road conditions.

This fitment instruction is applicable to all variations of Front Filler Kits, take note of which steps are applicable to a specific model.



Service Enquiries email
queries@alu-cab.com

Installation Instructions

The tables below show the equipment, tools and fasteners required to install the **INEOS GRENADIER - SAFARI WINDOW SPACER BRACKET**

Tools & Items Required
13mm Socket and Socket Wrench
13mm Ratchet Spanner

Fasteners Supplied	Qty
M6x50 HEX BOLT S/S	8



Please be sure to lay out all parts provided on a table or flat surface in order to check that all required parts are accounted for and prevent potential frustration at a later stage.

Installation Instructions

STEP 1

Ensure the load bars are unloaded and free to be removed. Unbolt the Load Bar from the left and right mounting feet.

Remove the M8 bolt that secured the load bar to the mounting feet, and substitute it for the M8x50mm bolt that is supplied.

Set the M8 Washer, M8 Nyloc Nut and M8 Nut Cap aside for reuse.





Installation Instructions

STEP 2

Install the load bar spacer bracket between the load bar and the mounting feet.

Ensure the small plane faces the load bar, and that the large split plane face faces the mounting feet.

Ensure the closed face of the spacer bracket faces outside.



Installation Instructions

STEP 3

Re-install the M8 Washer and M8 Nyloc nut that were removed in Step 2, do not tighten as yet.

Repeat the same steps for both load bars, and both left and right mounting positions.



Installation Instructions

STEP 4

Align the load bars, ensure that they are parallel. Tighten the M8 bolts to 16 N.m. dynamic torque.

Install M8 Nut Caps on 8 x M8 Nyloc Nuts.



DISCLAIMER

All rights reserved. No part of this website may be reproduced, translated, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of the owner.

Review all instructions information carefully before installation.

Any damages, direct or incidental to the installer and/or property due to incorrect installation of any parts are the responsibility of the installer. Due to the various applications and fitment options available, the responsibility lies with the user to ensure all mounting points are secure and tight before every trip.

If unsure, consult with your Distributor regarding the operations of our products.

Users are advised to be mindful of the load they are carrying and drive in accordance with road conditions.

WARNING

Always wear appropriate PPE (Personal protection equipment) when fitting our products. Although the mounting kit is designed to be DIY, if you have any doubts or concerns, contact an accredited fitment centre to carry out the work. Alu-Cab will not be liable for any injury to persons, and/or damage to products and/or vehicles.

While Alu-Cab Holdings takes reasonable measures to ensure that the contents of this Website are accurate and complete, Alu-Cab Holdings makes no representations or warranties, whether express or implied, as to the quality, timeliness, operation, integrity, availability or functionality of this Website or as to the accuracy, completeness or reliability of any information on this Website. Alu-Cab Holdings reserves the right to make changes, corrections and/or improvements to the information and to the products and programs described in such information, at any time without notice.

Alu-Cab Holdings will use reasonable endeavours to maintain the availability of the Website, except during scheduled maintenance periods, and reserves the right to discontinue providing the Website or the service or any part thereof with or without notice to you. Any person who accesses this Website or relies on this Website or on the information contained in this Website does so at his or her own risk.

Occasionally, at our discretion, we may include or offer third-party products or services on our website. These third-party sites have separate and independent privacy policies. We therefore have no responsibility or liability for the content and activities of these linked sites. Nonetheless, we seek to protect the integrity of our site and welcome any feedback about these sites.